



**MAKING YOUR DREAMS A REALITY**

## **FITTING INSTRUCTIONS**

### **TPER-0113 Steering Stopper, Honda VFR750R RC36-2 (94-97)**



Fitting the TYGA TPER-0113 Steering Stopper to the RC36-2 is a simple and straight forward task. However, it is a necessary part when fitting the TYGA RC36-2/RC30 style bodywork kits, to limit steering lock and avoid interference between the handle bars and other components.

All you need to do is to remove the horn/brake hose bracket, hook the steering stopper over the cast stoppers on the original lower clamp, line up the mounting hole with the central M6 mounting hole for the horn/brake hose bracket, and then bolt the bracket back on over the top.

Job done.

