



MAKING YOUR DREAMS A REALITY

## FITTING INSTRUCTIONS

NC30/35 Steering Stopper (TPER-0017/ TPER-0018)





It is easiest to fit the steering stopper with at least the upper cowling removed to allow easy access and clear viewing.

1. Remove the bolt securing the horn. this bolt hole will be used to secure the steering stopper.
2. Remove the bolt securing the brake line stays and pull this out of the way (NC30 only).
3. Hook the right hand side of the TYGA steering stopper over the original stopper cast into the lower clamp.
4. Slide the securing lug of the TYGA steering stopper under the horn mount. This will be secured with the original horn bolt at final fastening.
5. Hook the left side of the TYGA steering stopper over the original stopper cast into the lower clamp.
6. Check alignment of securing hole on TYGA steering stopper with hole in lower clamp, and then refit the horn and secure with the original bolt.
7. Refit brake line stay (NC30 only).
8. Check full lock left and right to check that the steering stopper is working correctly and will not catch any wires or cables.

[www.tyga-performance.com](http://www.tyga-performance.com)